



## Cylinder for Altoelsammler (item for CT4101) 2097

Cylinder for CT4101 Altoelsammler (1 pc.)

### Instructions:

- Air supply must be filtered of water and oil impurities before connecting to the bank. Air supply is to be 87 psi ~ 116 psi (6bar ~ 8bar)
- Temperature of oil shouldn't be higher than 60 °C, oil temperature of 40-60 °C is suggested.
- Please ensure the valve which connect between the tank and cylinder is closed for oil draining, air pressure in the tank is not allow to get into the cylinder, otherwise it could lead to explosion of cylinder and cause body injury.
- Tank pressure of 0,7 bar (10 psi) for oil extraction, the maximum air pressure is nor allow to exceed 1bar (14,5 psi). Please make sure to evacuate the residual compressed air out of the tank before the next time use.